

ARICA – výměna horního litinového víka

NORDFLAM

ARICA - replacing the top iron cover



1. Open the stove door as wide as possible.



2. Locate the deflector, lift it slightly, move it to the right and pull it down from the left side.



3. Remove the nuts and washers that secure the cover to the side walls.



4. Unscrew the stub pipe, then remove the old cover and unscrew the 4 headless screws from it.



5. Take the new cover, bolt in 4 screws, apply the weld (green line) and place the insulating cord along its entire length.



6. Put the new cover on the stove, then screw the stub pipe to it.



7. Screw the cover on both sides to the side walls using nuts and washers.



8. Place the deflector back into the stove by inserting it at an angle, first the right side, then the left side.

1. Otevřete dvířka kamen co nejvíce.
2. Najděte deflektor, mírně jej nadzvedněte, posuňte doprava a na levé straně jej stáhněte dolů.
3. Odstraňte matice a podložky, které upevňují horní víko k bočním stěnám.
4. Odšroubujte kouřové hrdlo, poté sejměte staré horní víko a vyšroubujte z něj 4 bezhlavé šrouby.
5. Vezměte nové víko, zašroubujte do něj 4 šrouby, naneste těsnicí tmel (zeleně vyznačená linie) a po celé délce uložte těsnicí šňůru.
6. Nasad'te nové víko na kamna a následně k němu přišroubujte kouřové hrdlo.
7. Přišroubujte víko na obou stranách k bočním stěnám pomocí matic a podložek.
8. Vložte deflektor zpět do kamen pod úhlem – nejprve pravou stranu a poté levou.